Global Ventures Australia

ABN 77 065 255 763

Eco-Core SVL Flooring European Beech STORAGE, HANDLING, CARE AND MAINTENANCE

SECTION 1 COMPANY IDENTIFICATION

Company Name	Global Ventures Australia Pty Ltd
Address	Unit 13 / 22 Beaumont Road Mount Kuring Gai NSW 2080 Australia
Phone	+ 61 2 9457 7171
Website	www.ecocore.com.au
Email	enquiries@globalventures.com.au

SECTION 2 STORAGE AND HANDLING

Storage & Handling	Sheets should be stored flat, preferably in a slightly elevated 100% level platform in a clean and dry environment away from water, moisture, humidity and direct sunlight. It must not be subjected to extreme temperatures. Never store sheets upright or diagonally against a wall or table. This product needs to be acclimatised, as per the installation recommendation provided to you. However, if you will store the product for a long period, it is best stored in the original packaging with cover sheets top and bottom until it is needed. Never leave sheets exposed without cover sheets unless you are in the process of acclimatising the product.
--------------------	---

SECTION 3 CARE & MAINTENANCE

Care & Maintenance	As the product is supplied raw, instructions for the care and maintenance should be sourced from the supplier of the coating, seal or finish that will be applied to the product.
--------------------	---

SECTION 4 MOISTURE AND HOW IT AFFECTS TIMBER

Effects of Moisture on Timber	Timber is a natural product and is hygroscopic in nature and will respond to different levels of humidity and moisture. When moisture is absorbed timber will expand and will shrink when moisture is lost.
	This means that even though the timber has been dried, cut, and processed into flooring material, the timber may expand or contract because of moisture. A change in season is when these changes become more significant. Timber flooring may expand during warm and humid summers and contract during dry winter weather. Seasonal movement is normal for timber products, these changes are also caused by indoor climate. The best way to reduce such movement is by keeping a constant level of humidity, please refer to the installation recommendation.

Failure to follow this advise may affect your warranty. If you have any concerns regarding any information contained in this document please contact Global Ventures Australia before you proceed.